

PENTAX MOUNT ADAPTER K OPERATING MANUAL

How to use the PENTAX mount adapter K

This adapter is used to attach the conventional TAKUMAR screw-mount lens to the PENTAX K mount camera.



The distance scale of the lens can be used as it is and picture taking is possible up to infinity. However, the automatic diaphragm of the lens will not function, so meter reading must be made with the lens aperture stopped down.

- (1) Fit in the adapter, matching the red dot of the adapter with the red dot of the body mount.
- (2) Turn the adapter clockwise until it stops (65°) by using a ball-point pen or the like to lock it.

Then screw-mount lenses can be used.

- (3) To remove the adapter, push the spring with a ball-point pen and turn the adaptor counter-clockwise until it stops.

- The accessories (auto extension tube, helicoid extension tube, etc.) can be used in a similar way.



Asahi Optical Co., Ltd. C.P.O. 895, Tokyo 100-91, JAPAN
Pentax Europe n.v. Weiveldiaan 3-5, 1830 Zaventem, BELGIUM
Pentax Handelsgesellschaft mbH Postfach 54 0169, 2000 Hamburg 54, WEST GERMANY
Pentax U.K. Limited Pentax House, South Hill Avenue, South Harrow, Middlesex HA2 0LT, U.K.
Pentax France S.A. Z.I. Argenteuil, 12, Rue Ambroise-Croizat, 95100 Argenteuil, FRANCE
Pentax (Schweiz) AG Industriestrasse 2, 8305 Dattikon ZH, SWITZERLAND
Pentax Scandinavia AB Box 650, S-751 27 Uppsala, SWEDEN
Pentax Nederland Spinveld 25, 4815 HR Breda, THE NETHERLANDS
Pentax Norge A.S. Cecilie Thorsens Vei, Lambertseter, 1101 Oslo 11, NORWAY
Pentax Corporation 35 Inverness Drive East, Englewood, Colorado 80112, U.S.A.
Pentax Canada Inc. 3131 Inverness Drive, Mississauga, Ontario L4X 2E5, CANADA
Asahi Optical Brasileira Ind. e Com. Ltda. Rua Capitão Antonio Rosa 376, Sala 121 Ed. PBK, São Paulo, BRASIL